

Instruction Manual



OM2000 HF "one phase" SHORTWAVE POWER AMPLIFIER

**OM POWER, s. r. o. 930 30 Báč 126
SLOVAKIA**

Important safety instructions:

- The amplifier contains high voltage circuits. Never turn the amplifier on without the upper lid in place.
- The OM2000 HF amplifier is not to be used in a wet or humid environment not to be exposed to rainfall.
- The amplifier must be installed in such a way that free flow of hot air from the tube is allowed. The amplifier must not be installed in a constrained surrounding (i.e. tight shelves etc.)
- During long operation the upper lid and the vent grid of the amplifier can reach high temperatures that can cause burn injuries. Do not touch these parts of the amplifier during operation.
- The amplifier must be grounded during operation.
- During operation the amplifier must be installed in such a way that the rear power supplies are accessible.
- Do not turn the amplifier on without having connected the antenna. A hazardous HF voltage may built up on the antenna connector after turning the amplifier on with no antenna connected.
- Before opening the upper lid of the amplifier make sure that both power suppliers have been disconnected for at least 5 minutes allowing the electrolytic capacitors to discharge fully. Never turn the amplifier on without the upper lid in place.
- Make sure that all screws holding the case together are properly in place and tried before carrying the amplifier by the handles.
- The amplifier is an A category product. In a household it can influence other electric appliances. In such cases the user is to take proper actions to mitigate this disturbance.

General description of the OM2000 HF Amplifier

The linear amplifier OM2000 HF is designed for all short wave amateur bands from 1.8 till 29 MHz (including WARC – bands) and all modes . It is equipped with a ceramic tetrode GU84b.

Specification of OM2000 HF:

Frequency coverage:	amateur bands 1.8 – 29.7 MHz including WARC
Power output:	2000+ W in SSB and CW 1500+ W in RTTY, AM and FM
Driver power:	usually 40 to 60 W for full Output Power
Input impedance:	50 Ohm VSWR < 1.5 : 1
Output amplification:	17 dB
Output impedance:	50 Ohm unbalanced
Maximum output SWR:	2:1
SWR protection:	automatic switching to STBY, when reflected power is 350W or higher
Intermodulation distortion:	32 dB below nominal output
Suppression of harmonics:	< -50 dBc
Tube:	GU84b Ceramic tetrode
Cooling:	Centrifugal blower
Power supply:	1 x 230 V - 50 Hz one phase
Transformers:	1 pc of toroidal transformer 2,5 kVA
Protection circuits:	<ul style="list-style-type: none">- SWR too high- Anode current too high- screen current too high- grid current too high- Mistuning of power amplifier- Hot switching protection- Soft start for protecting your fuses- “switch –on blocking “ at opened amplifier
Bar graph indications:	<ul style="list-style-type: none">- Power output – bargraph 50 LED- reflected power – bargraph 20 LED- screen current (I_{g2} – bar graph 10 LED)- anode voltage, anode current, tuning – bargraph 30 LED
LED indicators :	grid current (I _{g1} – 2 LED) WAIT – preheating of tube (180sec) STBY - standby OPR – operating condition FAULT – failure, switching off for abt. 2 sec
Parameters:	485 x 200 x 455mm (width x height x depth)
Weight:	28 kg


General Description of OM2000 HF POWER AMPLIFIER

HF PART

In this amplifier a tetrode GU84b is used in a grounded-cathode circuit (input into control grid). This amplifier achieves excellent linearity by the voltage stabilization of the control grid bias and the screen voltage. The power input is given to the control grid, using a broadband input circuit with an input impedance of 50 Ohms. This adaptable input circuitry ensures a good input SWR better than 1.5:1 on all short-wave bands.

The output of the amplifier is a Pi-L circuit. The ceramic capacitor for TUNE and LOAD are divided. This enables the amplifier to be tuned exactly and makes it possible to easily return to the previously set positions after band change.

Top view on the opened OM2000 HF



POWER SUPPLY

Power supply of the amplifier is effected by one 2.5 kVA toroidal transformer. A soft start is realized with the help of relays and resistors.

The high anode voltage consists of 8 times 350 V and 1,5 A. Each of them has its own rectifier and filter. In the high voltage circuit safety resistors are employed to protect the amplifier against overload. The source for screen grid is stabilized by a parallel stabilizer with BU508 transistors and delivers a voltage of 360V at 100mA.

The -120V for the control grid is stabilized by means of zener diodes.


SAFETY DEVICES

Control and monitoring circuits ensure control and safety of the circuits of the device during malfunction of the PA. They are placed on the Control board, which is located on the subpanel.

Putting the power amplifier into operation

Coaxial cable

The output of the transceiver is to be connected with the input of the amplifier via RG58 or similar cable. For the connection between the power amplifier and the antenna RG213 or similar coaxial cable suited for this high power is to be used. For INPUT and OUTPUT PL-259-sockets with Teflon isolation are used.



Rear view of the amplifier

Control cable

With the control cable ensures switching from reception to transmission. The cable is shielded. On the side of the power amplifier a CINCH-socket is used. On the side of your transceiver you have to use a socket suitable for this transceiver. During transmitting the middle pin is connected to the ground.

The relays of the OM2000 HF have to be switched earlier than HF is applied (cold switching).

Modern transceivers have a time delay between PTT switching and power output.

If you are using an older transceiver or transmitters without time delay we recommend to connect the PA in such a way that the transmit/ receive switch is connected with the KEY IN socket of the amplifier. The KEY OUT socket is to be connected with the PTT socket at the transceiver.

The amplifier is equipped with two safety devices, which ensure that the Output relay is not switched under power mistakenly (hot switching).

MAIN SUPPLY:

The amplifier is connected to the mains with 1 cable with an EURO end.

Grounding

The amplifier has to be grounded properly! Connect the screw on the rear panel of the amplifier to your local grounding system with a copper-cable, use a cross-section of 4 mm² at least.

Connect your transceiver to the same grounding system of your shack carefully!

If you use a power amplifier with higher output you have to be aware that your grounding system works properly. **All parts have to be grounded to the same system.** Use short cables and make sure that there are good contacts! Otherwise you run the risk of damaging your equipment, having problems with TVI/BCI or your signal may be distorted.

Cooling

The centrifugal blowers provide the necessary cooling of the amplifier, even during long contests. The main blower is activated by switching the PA on and it is turned off when after-cooling is finished (approx. 1-5 min after switching off the PA depending on the temperature of the tube).

Operation

Operating elements (see photo of front panel)

- BAND** - band selector switch (in MHz)
- TUNE** - Anode capacitor for tuning, tuning of higher frequencies to "0", lower frequencies to „100“.
- LOAD** - Output capacitor tunes antenna load resistance to amplifier.
Capacity is low at „0“ and high at "100" on the scale.
- OFF** - You switch off the amplifier by pressing this button.
- ON** - You switch on the amplifier by pressing this button.
Heating of tube is on and after 3min of delay the amplifier will be ready for operation.
- OPR/STBY** - „OPERATE“you will be ready for operation.
At STBY, if WAIT-LED is on or the amplifier is off your transceiver is in bypass-mode directly connected to antenna. Maximum 400 Watts !
- RF OUTPUT** - Bar graph – shows output power .
- REFLECTED POWER** - Bar graph – shows reflected power of the antenna. 350W maximum or amplifier switches to STANDBY-mode
- Ig2** bargraph – measures the current of the second grid in the range from -20mA to +80mA
- HV/IP/TUNE** bargraph – measure the anode voltage, anode current or tuning of the amplifier

TUNING

The OM2000 HF amplifier is operated in class AB. Thus it's possible to obtain a maximum output power at an excellent linearity. For this purpose the amplifier has to be tuned carefully. The operation of a mistuned PA will cause malfunctions, the increase of grid current (the GRID-MAX-LED will light up) and problems with TVI/BCI.

The grid-current is shown with 2 LED diodes. It's normal if the green LED is flashing or may be shining a little bit during peak operation. If you overload the amplifier the output power increases the grid current at very small rates and the red GRID-MAX-LED is shining and the safety devices switch the PA to STBY. You must decrease the output power.

In SSB you will have a good output power if the green LED lights up a bit. The current of screen grid is measured and shown in a Bar graph indicator. The amplifier has to be tuned in such a way that the current is between - 20 mA to +50 mA. At currents beyond these values the operating point will be shifted and IM-products will be rapidly increased. If a value of + 70mA is exceeded, the safety devices will switch the amplifier to STBY mode.

Tuning instruction:

Please note:

Before starting tuning you have to check if the right antenna or a 50 Ohms load resistance is connected at the antenna output!

Switching on the amplifier:

- put the switch at the multimeter to HV position
- put the OPR/STBY switch to STBY position
- press the „ON“ button

The amplifier is prepared for operation with the following steps:

- the toroidal transformers are switched step by step.
- the blower of tube is switched on.
- the multimeter bargraph measures the high voltage; the normal value is 2,8 kV
- the WAIT LED lights up

After switching on you have to check the functioning of the blower. Air must be blown out of the ventilating apertures above the tube. (If there is any failure you have to press the „OFF“-button immediately !)

Heating the tube takes about 150 seconds. After this time the WAIT LED goes out and the amplifier is ready for operation.

Tuning the amplifier to an output of 2000W

1. Switch BAND, TUNE and LOAD to the position according to the table:

Band	Tune	Load
1.8	45	40
3.5	60	34
7	44	64
10	80	8
14	72	30
18	70	35
21	32	56
24	48	50
28	25	62

The tuning table available to you is made by using a dummy load! Each amplifier will have other values depending on used frequency and antenna! Make your own list for your own antennas! Use tuning position (see later)!

2. Reduce the power output of your transceiver to the **0**.
3. Switch **OPR/STBY** to „**OPR**“ position (OPR LED lights up)
4. Choose **TUNE** position of multimeter.
5. Switch the PA to **CW** and increase driver power to **10W** (OUTPUT power will be abt. 500W)

Please note!

If the input power is higher than 15 W and the power amplifier is not correctly tuned, the safety devices will switch to STBY.

After switching the amplifier to PTT, the amplifier will automatically reset and switch back to OPR mode after approximately 2 seconds.

6. Set TUNE in such a way, that the TUNE-LED lights up maximum left.
7. Set LOAD in such a way, that the TUNE LED on the TUNE scale lights up under the “V” sign. If it is possible to obtain the LOAD in 2 positions, set the position that is farther to the right.
8. Repeat tuning several times according to 6 and 7.
9. Increase the input power until an output power of approximately 2000 W is reached.
10. Repeat steps 6 and 7
11. Set TUNE to maximum output power

After this procedure the amplifier is tuned correctly and ready to give 2000 W output power in all operation modes. At optimal tuning and full output power a positive 50mA voltage goes through the second grid. On 24 and 28 MHz bands optimal tuning can be achieved when one or two LEDs are lit up to the left from the position “V”. If less output is desired you can simply decrease the load of the transceiver.

Please note: Should the amplifier demonstrate any malfunctions during tuning or should it not behave in accordance with the description, interrupt the tuning procedure immediately and check the amplifier! Be sure to have not done any mistakes in choosing bands or TUNE/LOAD values!

Be sure that SWR is not higher than 1:2 and input power is LOW! After cancelling human mistakes you will be able to work for long time with this amplifier!

Indication of fault conditions

OM2000 HF has the following indication LED on the front panel:

GRID MIN	- indication of first grid current
GRID MAX	- max. First grid current exceeded
HV	- measuring of anode voltage by bargraph
IP	- measuring of anode current by bargraph
FAULT	- fault
OPR	- amplifier in operation mode
STBY	- amplifier in standby mode
WAIT	- heating of tube after switching on the amplifier

Should a fault condition appear during the tuning or operation of the amplifier the safety circuits of OM2000 HF will react. The amplifier will be turned to STBY mode. After approx. 1 sec the control circuits will switch the amplifier back to OPR. If the fault will repeat 3 times after each other the control circuits will turn the amplifier to STBY. Bringing the amplifier to OPR is enabled by using the OPR/STBY switch.

After the reaction of safety circuits the FAULT LED will be lit up for approx. 5 sec depending on the nature of the fault.

Flashing LED signalizes:

IP	- anode current exceeded
HV	- low anode voltage
FAULT	- reflected output exceeded
GRID MAX	- first grid current exceeded
	- screen grid current exceeded
GRID MAX + HV	- maximum load power exceeded
GRID MAX + IP	- zero output power during tuning
HV + IP	- tuning fault, incorrect tuning of the Pi-L output circuit

In case your OM2000 HF amplifier is not working, please contact the manufacturer,

**Contact: OM POWER, s.r.o.
930 30 Báč 126
SLOVAKIA**

Hotline FAX : +421 31 550 11 72

e-mail: om-power@om-power.com