

## M802 Radio

### How to Check the DSP Revision Number

The following procedure applies to all versions of the M802. The DSP version displays in the adjustment mode main screen. To enter the adjustment mode:

1. Turn the power off.
2. Press and hold the HM-135 DOWN key and the radio TX and RX keys, then turn the power on. Alternately, you can install a 15kΩ resistor between pins 2 and 6 of the MIC connector instead of holding down the HM-135 DOWN key.

