

YAESU FT-736R

EXPANDED RF

1. Unplug the power from the radio.
2. Open the radio and locate the 144 MHz main unit.
3. Locate diodes D24, D25, D26 and D27 See drawing.
4. Remove or install the diodes per table 1.
5. Reassemble radio.

D24	D25	D26	D27	
○	●	●	○	144.0 - 148.0 MHz
○	●	●	●	141.0 - 154.0 MHz
○	○	●	●	144.0 - 146.0 MHz

- Installed
○ Removed

