


ICOM INSTRUCTIONS

DESKTOP MICROPHONE

SM-20

Downloaded by
RadioAmateur.EU


FRONT VIEW



- 1 FREQUENCY UP/DOWN SWITCHES [UP] / [DOWN]**
Change the frequency up or down. Some transceivers do not have this function.
- 2 PTT SWITCH**
Push to transmit, then release to receive.
- 3 PTT LOCK SWITCH [LOCK]**
Push IN to transmit continuously, then push OUT to receive.

• MICROPHONE PIN CONNECTION

The pins are shown from the cable, or rear, side of the plug.




Thank you for purchasing the **SM-20 DESKTOP MICROPHONE**.

The **SM-20** is a unidirectional, electret microphone designed for base station operation with an Icom transceiver.

The **SM-20** cannot be used with a non-Icom transceiver since the power is supplied from the connected transceiver.

BOTTOM VIEW



- 4 MIC GAIN CONTROL [MIC GAIN]**
Varies microphone output level. Use this control when the connected transceiver has no mic gain controls.
- 5 LOW CUT SWITCH [LOW CUT]**
Cuts out low-frequency components of input voice signals.

NOTE: Rotating the control too far clockwise may result in overmodulation and transmit signal distortion.