


Expansion Range

The Exact range of this radio is not know as of press time. However most radios expand from .5Mhz - 30 Mhz.

Expanded RF Modification

1. Remove Power and antenna.
2. Remove screws and open radio.
3. Locate Logic board
(Board B42918)
4. **Remove Jumper chip W1.**
5. Reassemble the radio.
6. Reset the microprocessor if needed.
(press [CLEAR] & turn power on)



Radio/Tech Modifications Volume A

Photocopies are a violation of copyright law. © artsci inc. all rights reserved.
Have the original book with you when you call with a question. **Use at your own Risk!**
The Author and all other parties take no responsibility for any damages or violations caused by these modifications. Some modifications may violate FCC rules.
(818) 843-4080 12-4 PST • www.artscipub.com • artsci@artscipub.com

© artsci