


Expansion Range

The Exact range of this radio is not know as of press time. However most radios expand from 141 Mhz - 151 Mhz.



Expanded RF Modification

1. Disconnect the battery and antenna.
2. Remove the 3 screws holding on the back cover.
3. Remove the 2 screws on the bottom of the radio.
4. Unsolder the tabs of the lithium battery.
5. **Unsolder Diode D14.**
6. **Install the diode in the location next to D12.**
7. Reinstall the lithium battery.
8. Reassemble the radio.

