

MASTER
Do Not Remove
From Tech Support Area

```

-NOTE- The IC-M600 should now display one of the three
- modes: "H3E", "R3E" or "J3E" located in the upper
- right hand corner of the LCD. Also, the letters
- "RCV" and a reverse displayed "TX" should be
- displayed in the upper left hand corner of the LCD.
- The rest of the LCD will be blank.

```

- TO ALLOW CONTINUOUS TRANSMIT COVERAGE FROM 2 TO 26.999 MHz. (Logic Board)
1. Remove D8 and D15 on the Logic unit. HAWAII

