

Enabling the Icom M803 Amateur Mode*

* Amateur Radio General Class license or higher required for *transmitting* on Ham Bands.


1 - Turn OFF Radio

2 - Simultaneously press and hold the 2, RX/TX, and MENU buttons, while powering ON the M803

3 - Continue depressing the 2, RX/TX, and MENU buttons until the radio show's its normal operating screen

4 - When enabled, AMATEUR will appear on the upper right portion of the M803's display

Before Enabling



After Enabling

