

	R3	R13	R16	R17	JP3
T, TG	NC	NC	O	NC	JUMPER
E, EG	NC	O	NC	NC	JUMPER
TA, TAG	NC	NC	O	NC	NC

JP3 JUMPER CUT FOR TX/RX EXPANSION. RESET: PUSH AND HOLDING FUNC KEY THEN TURN ON RADIO.

The top view of the PCB shows a large central rectangular area, likely for a display or sensor. Surrounding this area are various components: a circular connector on the left, a square connector on the top left, a square connector on the top right, a square connector on the bottom right, and a circular connector on the bottom right. A small component labeled JP4 is located near the bottom center.

For CH display: Input data and short JP4.