

Expansion Range


.1 - 30 Mhz.

Remember that the electronic circuits can only tune a 20-30 MHz window around the original center frequency (tuned at the factory) you may have better performance at the top or the bottom ends of the tuneable range.

FT-1000 FRONT PANEL

FT-1000
Control Unit

Remove Solder
Bridge from
Pad #3



Expanded RF Modification

1. Remove power from the radio.
2. Open the case top and bottom.
3. Locate four screws attaching front panel and remove the top screws. Loosen the bottom screws.
4. Tilt front panel forward.
5. On the left side of the radio, remove the plug from the power supply to the front panel. (gray and white wires)
6. Locate jumper position 3 on Control board.
7. **Unsolder the jumper in position 3**
8. Reassemble the radio.
9. **Reset the microprocessor.**
(Turn off the Backup Switch, located inside the panel window)

Expanded RF Modification FT-1000MP

1. Press [LOCK] & [FAST] and turn the radio on.
2. Press [FAST] & [ENT] keys.
3. Select [9 - 9] on the memory channel block by turning [MEM/VFO] knob COUNTERCLOCKWISE.
4. Select [GEn] by turning the main dial.
5. Press and release the [ENT] key.

Before 15 000 9 - 9 CH

After GEn 000 9 - 9 CH

To restore amateur bands only:

1. Press [FAST] & [ENT] keys.
2. Select [15] by turning the main dial then press [ENT] key.