INSTRUCTION MANUAL

SOMMER DJ2UT MULTI-BAND ANTENNA

XP 50 SERIES

SOMMER ANTENNAS 395 W. OSCISOLA ROAL P.O.BOX 710 GENEVA FL 32732

Pages 403-349-9134 - PAE 407-349-2465 E-mail: sommer Light nelcots.com Sarp., / www.assamcestensor.com

GENERAL INSTRUCTIONS

The Sommer XP50 series antenna may appear to be complicated at first glance, however, it can be easily assembled by following the assembly stops carefully.

Each element to be attached to the double-tube boom is color coded as to its location.

Each of the center element support brackets has been preassembled to simplify assembly.

The length of each element tube and the spacings between the elements along the boom are clearly shown in the Figures.

All boits, screws, washers, nuts, clamps and other hardware are stainless steel for long life, and freedom from corrosion. Before installing nuts on the boits, place a drop of light oil (such as 3-IM-1) on the threads. Make certain that lockwashers are used on all boits and screws, and that all screws and nuts are "snug". Do not over tighten!

Before raising the antenna, make a double check of all element clamps. You may save having to lower the antenna to readjust an element length!

SOMMER ANTENNAS

395 W. OSCEOLA ROAD P.O.BOX 710 GENEVA FL 32732 Phone 407-349-9114 Fax 407-349-2485 e-mail: sommer1@ix.netcom.com

INTRODUCTION

This instruction manual covers the Sommer Models XP504, XP605, XP508 and XP508. The last number is the number of amateur bands covered by that model. The first set of steps are those that are common to all models and will produce the model XP504.

XP504 does not include Element-1C (BLUE-RED). Additional steps for the other models follow.

XP50(4-8) ANTENNA ASSEMBLY

The following steps should be performed using the Figure A during each step, and the detailed instructions as noted. The stanlass steel bolts require a 1/2" or a 13 mm metric wrench, and the samell nuts require a 7/16" or a 11 mm metric wrench, and the screwdriver is also required. A steel tape measure is recommended for setting spacings and lengths.

A77 Mode7s

STEP 7

If your boom came in sections, please assemble them first as shown in the FIG.-Boom- $\,$

Now place the two boom tubes on edge on a flat surface, spaced about 1" (25 mm) apart. Even up the ends. Place several blocks or a pair of saw horses under the boom tubes to facilitate mounting of the elements.

Select the YELLOW LOG-Element center support bracket, and the two 1" D. (25 mm D.) tubes having the yellow bands. Insert the non-slotted ends in the slotted ends of the 13/8" (30mm) D. tubes of the LOG-3 element mounted on the support bracket. Adjust the length of each 1" tube as shown in Figure A.

Select the pair of T-match tubes. Insert one end of each T-match line through the hole of the respective outer blue Lexame insulators as shown in Figure 8. Attach the outer ends of the T-match tubes to the 1° YELLOW (GO-Fiement tubes by use of the two parts of the Committee of

Place the VELLOW LOG assembly on the boom tubes at one end, spaced about 1/4" to 1/2" (1-2 on) from the ends. See FIG. C. (This will be the REAR end of the antenna.) Make sure that the boom tubes seat in the two support bracket notches. Select the U-channel having the "M" stub line attached. After oiling the bracket botter threads, insert the three bolts through the U-channel of the boar and through the support of the boar and through the support of the boar and through the support of the boar and note on the upper ends of the bolts and thisten uniformly.

STEP

Attach the "W" stub tuning line stub to the YELLOW LOG-Elements by means of the screws adjacent the blue insulators as shown in FIG. C.

Attach the open end of the first set of phasing lines to the center of the YELLOW LOG-T-master lines with the phasing lines toward the front end of the boom.

STEP 5:

Place the element support bracket having the GREEM LOG-Elements on the boom tubes adjacent the crossed ends of the first phasing lines to the place of the place of the control of the place of the control of th

Loosen the clamps on the phasing lines and connect the crossed ends of the lines to the GREEN LOG-Elements with the screws provided. Tighten the clamps.

Attach the second phasing line to the GREEN LOG-T-match with the lines and cross connections toward the front end of the boom.

STEP BI

Refer to FIG. E which shows details of the group of elements EL-1A, EL-1B and BLACK LOG-1 (EL-1C is not used in the XP504 model.)

Place the element support bracket having the BLACK LOG-I elements on the boom tubes adjacent the crossed ends of the second phasing lines with the T-match facing toward the front end of the boom as shown in FIG. E (TOP VLBW). Install the U-channel with the three bolts as in the previous steps, and adjust the spacing the property of the space of the space of the two courses of the space of the two courses of the two query bolts, leaving the nut on the center bolt lose.

Connect the cross connection straps of the second phasing line to the screws of the inner ends of the LOG-1 tubes. Loosely mount BLUE EL-18 to the boom spaced about 15" (38 cm) from the LOG-1 element. Install the EL-18 feed lines between LOG-1 T-match terminals and the screws on the EL-18 tubes. Please bend the feed lines - do not shorten them ! Tighten the element support bracket bolts.

Refarring to FIG. E (SIDE VIEW) place the cast aluminum bracket on the boom, spaced about 7" (18 cm) from EL-18. Install a Uchannel on the aluminum bracket, aligning the bolt holes, and place SULE-BLACK EL-1A center element in the U-channel. Install the two bolts through the lower U-channel and through the top channel and elements the may set the spacing from EL-18 to 7" (16 cm) and elements the set of the set of

STEP 8:

Place the balum in front of the LOG-1-T-match. See FIG. F+E. Attach the two leads from the top of the balum to the point at LOG-1 where its T-match connections meet with the feed lines coming from EL-18 (and EL-1C if your antenna is equipped with the 17 m band)

Attach the terminal from the bottom of the balun to the LOG-1 Uchannel. A hole is predrilled there and screws are premounted. Place the terminal between the two stainless steel washers.

Your balun as well as the inner conductor of the coax feedline are now DC-grounded via boom - mast - ground.

Connect your coax cable by soldering it to the piece of Teflon coax cable coming out from the bottom of the balun. See FIG.-Balun-Seal the connection with PVC tape to make it waterproof.

Connectors/plugs tend to take on humidity. As our experience shows, the result is that they often burn, You will save yourself a lot of trouble by using the above described method to connect your cable to the balun.

However: A silver Teflon PL259 included for your convenience!

BE SURE TO READ CAREFULLY THE ENCLOSED INFORMATION SHEET ABOUT USING THE PROPER COAXIAL CABLE. Using an inferior cable can seriously affect the tuning and performance of the antenna.

Note: The baluns Teflon coax cable is good for 10 kW output continuous at 10 MHz.

STEP 0:

Mount the RED-YELLOW Element on the boom. This element is DC-grounded to the boom. See FIG. A for distances.

Repeat the above step for the RED ELement, placing it ahead of the GREEN LOG-Element.

* If your antenna includes 40 meters, the RED-YELLOW ELement is insulated and mounted on a cast aluminum center support bracket. See STEP 14.

STEP 10:

Select the telescoping 1" (25 mm) 3/4" (20 mm) 5/8" (15 mm) and 1/2" (12 mm) element tubes. Insert the 1" tubes in the 1-1/2" (30 mm) center tube for each LOG-element and the EL-18 element, and set to the lengths shown in FIG. A.

STEP 11:

Refer to FIG. G-1 which shows details of the phasing line support. Element EL-3A, the RED-YELLOW element is shipped with a support clamp installed at the center of the tube. A insulating Lexan support is attached to the tube. Push the phasing lines through the holes.

Refer to FIG. G-2 which shows details of the phasing line support attached to element EL-2A. This element is grounded to the boom and mounted in a U-channel. The phasing line support is shipped attached to the EL-2A U-channel. Push the phasing tubes through the holes.

STEP 121

Your X807 antenna is now completely assembled. The next step is to attach the mast clamp. Referring to FIG. I, a top view and a side view are provided. Rest the antenna boom on a saw horse, or other best belance point, sark this point. Oil the he had been best belance point, sark this point. Oil the six boom clamp oil to a Assemble the four cast aluminum boom clamps with the four outer Assemble the four cast aluminum boom clamps with the four outer has a six been considered between the pair of his word of the six boom clamp boils. Mount for the two aluminum angle brackets between the pair of measuring carefully to center the assembly about the bilance boom measuring carefully to center the assembly about the bilance to the same than a standard of the two "chammels and boils. Install the mattenna on its mast, oil the four mast clamp boils. Install the

(Please note that the guy bracket and guys shown in FIG. H are not required for the XP507 antenna.)

Installation of 17 Meter Element

STEP 13

Loosely mount BLUE-RED Element to the boom spaced about 6.5" (18,5cm) should of BLAGK (LOS-1 element as shown in FIG. E. Install the EL-1C feedlings between the LOS-1 T-match terminals and the series on the EL-1C tubes as shown in the side view of FIG. Note: Please bend the feedline to its proper length - do not shorter.

hten the element support bracket bolts

EP 747

In STEP 9, you should have installed a RED-YELLOW EL-3A element having an <u>insulator</u> to insulate the element from the boom. This permits the element to work as a " C " on 40 meters.

Attach the 40 meter compensating coil to one of the T-match tubes of the YELLOW LOG-Element as shown in FIG. A-1.

Connect the other end of the coil to the RED-YELLOW ELement by the adjustable tubes as shown in FIG. F.

As will be described later, the coil can be tuned by stretching or shortening its length by means of the adjustable tubes.

Installation of 30 Meter Tuning System

STEP 15

Refer to FIG. J. Install the 30 m tuning unit to the flat aluminum straps forming the W-stub line by means of the flat connection straps and clamps. Before tightening the clamps adjust the spacing of the clamps from the U-channel as shown in FIG. J.

The 30 m band can be tuned in about 9 ft - 15 ft (3 - 5 m) height by moving it up and down the W-line. Moving it closer to the VELLOW element brings the frequency down - moving it in the opposite direction brings the frequency up.

It is recommended to mount it first in a distance of about 12 " + 2" (30 cm + 5 cm) from the YELLOW element.

IMPORTANCE OF YOUR TRANSMISSION LINE

The Sommer antennas are designed to be fed by a 50 che unbalanced coaxial cable via a i:! balum. However, the selection of the line is of great importance to the best operation of your antenna. All so-called 50 che coax lines are not suitable, even though the sealer may designate it as 88G/U luless it is stated that the line meets MIL SPEC, it may not. A problem with many types of coax lines is that their characteristic change drastically with see, heat, and excessive bending of the cable. For example, a line that use foam delectric may be desirable for low loss, the camter conductor can drift toward the copper braid, under heat and excessive bending. Cable may experience bending during rotation of the beam. These problems cause changes in VSWR over that when the cable was new.

The preferred cable for use with Sommer antennas is 80213/U. This cable handles 3800 watts, has at least 97% copper braid shield, and uses polyethylene dielectric. The center conductor is 13 AMG stranded copper. The loss is about 1/2 dB at 10 MHz, and the jacket is non containmating. If you experience any deterioration in VSMM or performance from the Sommer antenna, the feedline ist the first thing to cheep.

The antennas can handle the following power limits:

30 m: Legal power 300 W PEP out

40 m:

3-10-12-15-17-20 m

Legal power or - if allowed up to 7 KW - but only if your cable connection feedline to balun is done as recommended - no alway/connectors!

INITIAL ADJUSTMENTS

The element lengths specified in the assembly instructions are designed for an antenna height of about 45 to 80 feet. However, as with any horizontal radiator, the feed impedance is affected by the height above actual ground. As you may note from the ARRL Handbook, the center impedance of a half wave dipole will change from a few ohms to over 100 ohms as it is raised to about 0.3 wavelengths above a perfect ground. Another factor is the environment of the antenna. All conductive and lossy materials within the near field of the antenna will have an effect on the feed impedance, and consequently, the VSWR. Other antennas, utility lines, metal structures, and trees can influence the antenna.

The Sommer antenna can be adjusted to optimize the VSWM for each band so as to place the minimum VSWM in your favorite portion of each band. After setting the element lengths to the specified nominal values, it is helpful to temporarily support the boom at a height at which you can reach the elements, and to connect your feed line. Check the VSWM for each band, and record the values at the band edges, and at the frequency of the minimum value. If any value is very high (over 3, for example), check the lengths of the elements for that band. They may have shifted, or not correctly adjusted. The adjustment of the 40 m band will be discussed later.

If all values are reasonable, and you wish the minimums to be at different frequencies, this can be achieved by adjusting the lengths of the appropriate elements. A trial adjustment can be made using the following table. Lengthen or shorten the respective

elements on each side according to the following chart:

BA	N D	ELE	MENT	±	F O R 100 KHz
10	MTRS	EL-1A	(BLUE-BLACK)		± 3/8" (1cm)
12	MTRS	EL-2A	(RED)		± 5/8" (1,5cm)
15	MTRS	EL-1B	(BLUE)		± 3/4" -
17	MTRS	EL-1C	(BLUE-RED)		# 7/8" (2.5cm)
20	MTRS	LOG-1	(BLACK)		± 1 3/8" (3,5cm)

Sommer Antennas 395 W. Osceola Road Geneva FL 32732 Phone 407-349-9114 Fax 407-349-2485 sommer1@ix.netcom.com

Adjustment of 40 Meter System

At the height at which the antenna is usually erected, the 40 meter system is neitrively close to the ground. You may note from the ARRIL Handbook that the feed impedance of an antenna varies rapidly when a low height above ground is varied. Thus, the SMR for the 40 meter band is very sensitive to this problem. For this reason, it is common to need to trim it its adjustment during installation.

It is recommended that the antenna be temporarily mounted at about 10 to 15 feat above ground. Adjust the coil length by Tossening the clamp on the adjustment tubes and stretch or shorten the coil to carieve a SW or about 1.3 at the center of your desired operating range, or a minimum at the coil to the form of the strength of the coil to t

Stretching the coil moves the low SWR point to a higher frequency, and shortening the coil lowers that frequency.

Sommer Antennas 395 W. Osceola Road Geneva FL 32732 Phone 407-349-9114 Fax 407-349-2485 sommer1@ix.netcom.com







FIG. BOOM ASSENIULY




MOUNTING T-MATCH & PHASING LINE TO YELLOW LOG 3 ELEMENT

(Not to scale)











FIG. F DETAILS OF BALUN MOUNTING (Not to scale)

CONNECTION BALUN TO FEEDLINE



- 1. Remove the jackets of both cables. See FIG. 1
- Push the shield back as FIG. 2 shows and remove the inner conductors insulation.
- Connect the wires of the inner conductor together and solder the connection. FIG. 3
- 4. Wrap PVC tape around the inner conductor as FIG. 4 shows.
- 5. Connect both shields and solder. FIG. 5
- 5. Wrap with plenty of tape! PIG. 6




FIG. G DETAILS OF PHASING LINE SUPPORTS
(Not to scale)

FIG. G-2





FIG. H DETAILS OF MAST CLAMP

(Guy bracket and non-conductive guys are used only on 20 and 26 ft. broms.)






FIG. IK DETAILS OF 40 METER COIL AND TUNING SYSTEM