

D G S 1 *DRAKE*

DIGITAL FREQUENCY SYNTHESIZER

INSTRUCTION MANUAL

TABLE OF CONTENTS

SECTION	I :	GENERAL DESCRIPTIONS
SECTION	II :	CONNECTIONS TO RECEIVER
SECTION	III :	OPERATION
SECTION	IV :	SCHEMATIC DIAGRAMS
SECTION	V :	CRYSTALS INSERTION

SECTION I

GENERAL DESCRIPTION

The set is made with 2 main subsystems: a 0,5 MHz step crystal oscillator and a programmed counter.

A more detailed description is given by the block diagram of Fig.1.

The signal from injection is buffered and squared, before going to the counter's input gate.

The over range system of the counter is programmed in two different ways, depending if the 1st band starts with 0,0 MHz or 0,5 MHz.

The display is a 6 digits one, The last 4 nixies (on the right) are driven by the counter, while the first 2 (on the left) are connected with the 10 MHz and the 0,5 MHz selectors.

The oscillator gives a signal which is used instead of the receiver's first conversion crystal oscillator, and which can be changed in 0,5 MHz steps, so that coverage of the whole 0,5-30 MHz HF range is achieved.

The counter gives the exact frequency readout, in each 0,5 MHz sub-range, with 100 Hz resolution.




Fig. 1

SECTION III

OPERATION

- 1) Set the receiver's crystal-switch, in the 1st position.
- 2) Tune the band switch in accordance with the accessory operation instruction of the receiver's instruction manual.
- 3) Tune the 0,5 MHz and 10 MHz selectors of DGS1, in accordance with the beginning of the wanted band.
- 4) Tune the preselector control for the best sensitivity: be sure that the preselector is not tuned on image or other spurious signals, or the counter will not operate properly, and the receiver will not give the required sensitivity.

It is advisable to make a table, with exact preselector tuning, for any 500 KHz-wide band.

CAUTION

Due to the frequency tolerance of receiver's second conversion crystal oscillator, it will be necessary to adjust time base oscillator of DGS1, to get the best readout accuracy.

To adjust time base oscillator, remove the upper cabinet cover and internal box cover: T.B. trimmer is near crystal socket (See Fig. 8).

Tune a good standard signal (W.V.V. or a well known broadcast) and make zero beat on its carrier (it is preferable to monitor the beat with an oscilloscope on audio output): adjust T.B. trimmer until the exact frequency is read.




FIGURE 4

FIGURE 5





FIGURE 6



DGS1 (top view)

CONNECTIONS TO R4B/R4C RECEIVER

- 1) Connect the oscillator plug to the 1st accessory crystal socket through the HC6 adapter; ground connection must be fastened to the screw on the right the socket itself. (See Fig.2)





FIGURE 2

- 2) Connect the injection socket of the receiver to one of the socket on the rear panel of DGS1. If the receiver must be used in transceiver mode, the injection signal for the transmitter must be taken from the second socket of the DGS1 (which is internally connected to the first); See Fig.3

FIGURE 3



CONNECTION TO SPR4 RECEIVERS

Remove receiver's cabinet and connect HC25 adapter to the crystal socket N°1: red dot must be upside (see Fig.4) ground connection must be made with the screw on the side of crystals board.

Let coaxial cable go out of the cabinet through the central hole in the upper side, or through the same hole than speaker cable.

The oscillator plug of DGS1 must be fastened to the female connector of this cable.


Connect DGS1 counter input plug to injection socket: of course model TA-4 transceiver adaptor must be installed, in order to get this injection signal available.

For DGS1 remote switch-on, a female Jack must be installed in the hole under mute jack, and its contact must be connected to the pin of S-12 (dial lamp switch) connected to power transformer T7 (see Fig.5).


It will be necessary to change also the plug of the DGS1 remote switch cord, with a jack of the same type that the female installed on SPR4: the red wire of this cable must be soldered to the central connection.


Remove DGS1 cabinet and cut diode D1 leads: make a jumper as in(Fig.6) across C1.

(or brown)





Downloaded by
RadioAmateur.EU







S1=10MHZ Selector
S2=0,5MHZ Selector




9582



Counter amplifier






Time Base Oscillator



Power Supply


for SPR4 cut D1 and
make a jumper
across C1



View from cristals side

FIGURE 7

OSCILLATOR SECTION
TOP VIEW



COUNTER SECTION
TOP VIEW

FIGURE 8

