



Expanded RF Modification

Note: Accessing the main Board may require taking out many of the other components of the radio.

1. Remove power and antenna.
2. Remove screws and open top cover.
3. Remove screws and set PA unit aside.
4. Locate diodes D33 and D34 on the top of the PLL circuit board. (May be located under the heat sink)
5. Cut the Teflon covered leads of Diodes D33 and D34.
6. Reassemble the radio.

Radio/Tech Modifications Volume A

©artsci

Photocopies are a violation of copyright law. © artsci inc. all rights reserved.
Have the original book with you when you call with a question. **Use at your own Risk!**
The Author and all other parties take no responsibility for any damages or violations caused by these modifications. Some modifications may violate FCC rules.
(818) 843-4080 12-4 PST • www.artscipub.com • artsci@artscipub.com