




## Expansion Range

The Exact range of this radio is not know as of press time. However most radios expand from 138 Mhz - 165 Mhz.

**315 Range: 215 MHz - 230 MHz**


Remember that the electronic circuits can only tune a 20-30 MHz window around the original center frequency (tuned at the factory) you may have better performance at the top or the bottom ends of the tuneable range.

TH-215  
TH-225  
TH-315



## Expanded RF Modification

1. Disconnect the power and antenna.
2. Remove the 4 screws from the back panel.
3. Carefully lift the front panel from the radio. Do not disconnect the flex cables.
4. **CUT Jumpers shown below.** Select your radio.
5. Reassemble the radio.
6. **RESET the CPU.** (Press and hold [F] & [ENTER] and turn power on)



## Radio/Tech Modifications Volume A

Photocopies are a violation of copyright law. © artsci inc. all rights reserved.  
Have the original book with you when you call with a question. **Use at your own Risk!**  
The Author and all other parties take no responsibility for any damages or violations caused by these modifications. Some modifications may violate FCC rules.  
(818) 843-4080 12-4 PST • www.artscipub.com • artsci@artscipub.com

© artsci

