







Downloaded by  
RadioManual.EU




SCHEMATIC OF THE  
HEATHKIT®  
2KW LINEAR AMPLIFIER  
MODEL HL-2200


- NOTES:
1. ALL RESISTORS ARE 1/2 WATT UNLESS OTHERWISE INDICATED. VALUES ARE IN OHMS (K=1,000, M=1,000,000).
  2. CAPACITOR VALUES LESS THAN 1 ARE IN  $\mu$ F. VALUES OF 1 AND ABOVE ARE IN pF UNLESS MARKED OTHERWISE.
  3. THE BANDSWITCH IS IN THE 80 METER POSITION. ARROWS INDICATE THE DIRECTION OF ROTATION FOR THE VIEW SHOWN.
  4.  THIS SYMBOL INDICATES A CONNECTION TO CIRCUIT BOARD GROUND FOIL.
  5.  THIS SYMBOL INDICATES A CONNECTION TO THE CIRCUIT BOARD.
  6. PARTS IN SHADED AREAS ARE CRITICAL FOR CONTINUED SAFETY. REPLACE THEM ONLY WITH PARTS OF THE SAME RATING OR WITH THE PROPER HEATH PARTS.











Downloaded by  
RadioManual.EU